

1. Is a Stove Top Adapter required?

No; the adapter is not always required. If the inner liner of your pipe can fit inside of the collar on you stove the Adapter is not needed. Stoves with an outlet even slightly under 6" will need it.

2. What is the clearance to combustibles?

6" horizontal clearance to walls and an upper 8" clearance to ceiling or mantels.

3. Is it 2100° rated pipe?

Yes. Approved for use as a Class A connector 1000 F degrees.

4. Is it HUD approved for use in mobile homes?

Yes DVL® meets this standard for use in mobile homes where single wall is not permitted.

5. How can I reduce my clearance from 6"?

You can't; it would be up to your local building authority.

6. Can I paint it?

Yes. The DuraVent Engineering Dept. recommends Stove Bright Touch Up Paint, or any Hi-Temp stove paint.

7. Is the close clearance adapter required?

Yes. It is used to connect the support box or wall thimble. It also supports the pipe.

8. Why does my new DVL® stovepipe smell?

Our high temp paint is heat cured during the first few burns on a new system. see the Instruction Manual stating to open windows and provide ventilation until stovepipe is heat cured.